




DOBOT Magician V1/V2


INPUT / OUTPUT GUIDE


























DOBOT Magician

Digital Signal Guide








NEVER wire anything to the Dobot Magician while it has power **ON ALWAYS** shutdown the Dobot before making connections or damage to the robot could occur.

Parts Needed for Safe Communication

- Four Pin Male Headers
- Four Pin Jumper Wires
- 100Ω Resistors
- 4.7kΩ Resistors
- Breadboard
- Optical Isolators 4N25
- LEDs
- Jumper Wires
- Limit Switch



Test INPUT Communication to Dobot

- Four Pin Male Headers
- Four Pin Jumper Wires
- 4.7kΩ Resistors


Running Log: [17:07:08]0 [17:07:08]0

[17:07:08]0 [17:07:08]0


[17:07:08]1 [17:07:08]1

[17:07:08]1

- Breadboard
- Limit Switch











Test OUTPUT Communication from Dobot

- Four Pin Male Headers
- Four Pin Jumper Wires
- 100Ω Resistors
- Breadboard
- Optical Isolators 4N25
- LEDs











DOBOT Magician V1


Digital Signal Guide










Caution: NEVER wire anything to the Dobot Magician while making connections or damage to the robot could occur. it has power on. ALWAYS shutdown the Dobot before













DOBOT Magician V2





Digital Signal Guide


















GP1.1 **← √√√** 100Ω



Caution: NEVER wire anything to the Dobot Magician while

making connections or damage to the robot could occur. it has power on. ALWAYS shutdown the Dobot before



DOBOT Magician

Signal Guide




WARNING




Check Optical Isolator with Volt Meter

WHY is the robot not receiving a signal from the handshake module? Wiring and programing are often the culprit. It could also be a damaged optical isolator. The LED on the INPUT side of the optical isolator helps us determine if the signal is actually being sent by the robot. Unfortunately, the OUTPUT side of the optical isolator will not allow us to use an LED as an indicator. We can however use a volt meter to measure the RESISTANCE across the optical Isolator to determine when a signal is ON or OFF. Use the Blockly program shown below to cycle the signal ON and OFF to see if the signal is getting across the optical isolator. When no signal is present, the voltmeter should read "O.L" or "---". When a signal is present it should read near the resistance value of the resistor used.








Optical Isolator OFF = 0.L or ---Optical Isolator ON = $4.9 + k\Omega$

How to Use a Common GND

Can the ground (GND) be shared between multiple outputs? Yes, the ground can split among multiple optical isolators as a "shared" or common ground signal. The optical isolators then only need the signal wire to turn ON and OFF. See the illustration below.



Caution: NEVER wire anything to the Dobot Magician while shutdown the Dobot before occur could robot the <u>و</u> damage ō connections power on. making it has

